KOMATSU

# SHOP MANUAL

## DUMP TRUCK

SERIAL NUMBERS:
930E–5 A40067 - A40215

***930E–5***

**⚠ WARNING**

Unsafe use of this machine can cause serious injury or death. Read this manual before you operate or maintain this machine. Keep this manual near the machine for reference. All people who will come into contact with the machine should periodically review the manual.

**NOTICE**

Komatsu has Operation & Maintenance Manuals written in other languages. If an alternative language manual is necessary, contact your local distributor.

**Original Instruction**

**www.Komatsu.com**

**CEBM039402**

# 00 CONTENTS AND FOREWORD

# Contents


## 00 CONTENTS AND FOREWORD..... 00-1

Foreword..... 00-17
How to Read the Shop Manual..... 00-17
Safety Alert Symbol and Signal Words..... 00-18
General Precautions Common to Operation and Maintenance..... 00-19
Preparations for Safe Operation..... 00-19
Fire and Explosion Prevention..... 00-21
Precautions When Getting On or Off the Machine..... 00-24
Precautions for Cab and Working Around Machine..... 00-26
Precautions for Diesel Exhaust Fluid (DEF)..... 00-27
Operation Precautions..... 00-30
Precautions at Jobsite..... 00-30
Precautions in Starting Engine..... 00-31
Precautions During Operation..... 00-33
Maintenance Precautions..... 00-36
Precautions Before Inspection and Maintenance..... 00-36
Precautions During Inspection and Maintenance..... 00-41
Precautions for Electrical Equipment..... 00-49
Primary Causes of Wiring Harness Failure..... 00-49
Control Cabinet Capacitor Discharge..... 00-52
Hydraulic Equipment Precautions..... 00-53

## 01 SPECIFICATIONS..... 01-1

Specifications..... 01-2
Specifications: 930E-5..... 01-2
Recommended Fuel, Coolant, and Lubricant..... 01-3
Suspension Cylinder Oil and Nitrogen Specifications..... 01-4
Wheel Motor Oil Specifications..... 01-5

## 10 STRUCTURE AND FUNCTION..... 10-1

Steering System..... 10-2
Steering System Layout..... 10-2
Steering System Operation..... 10-2
Steering Bleeddown Manifold..... 10-4
Steering Control Unit..... 10-5
Steering Accumulators (Piston Type)..... 10-6
Steering/Brake Pump Operation..... 10-6
Flow Amplifier Operation..... 10-8
Hoist System..... 10-16
Hoist System Layout..... 10-16
Hoist System Operation..... 10-17
Hoist Control Valve..... 10-18
Hoist Pilot Valve..... 10-20
Brake System..... 10-21
Service Brake System Layout..... 10-21
Hydraulic Brake Cabinet Layout..... 10-22
Service Brake Operation..... 10-22
Parking Brake Operation..... 10-23
Brake Lock Operation..... 10-23
Secondary Braking and Auto Apply..... 10-24

Electrical System, 24V....10-25
Battery Power Supply....10-25
Battery Disconnect Switches....10-26
Engine Starting System....10-27
Auxiliary Control Cabinet Components....10-28
Body-Up Switch....10-30
Hoist Limit Switch....10-31
Automatic Lubrication (Auto Lube) System....10-32
Automatic Lubrication (Auto Lube) Grease Pump and Reservoir....10-32
Automatic Lubrication (Auto Lube) System Operation....10-33
Suspensions....10-35
Engine Emissions After-Treatment System Operations....10-36

**20 STANDARD VALUE TABLE....20-1**
Standard Value Table....20-2

**30 TEST AND ADJUST....30-1**
Hydraulic Systems....30-2
Hydraulic System Checkout Procedures....30-2
Hydraulic System Checkout Sheet....30-14
Steering System Leakage Check....30-17
Toe-In Adjustment....30-18
Hoist Cylinder Leakage Test....30-19
Steering Cylinder Leakage Test....30-19
Checking the Steering/Brake Pump Control Pressures....30-20
Adjusting the Steering/Brake Pump Control Pressures....30-21
High Altitude Steering/Brake Pump Adjustment....30-23
Brake System....30-24
Brake System Checkout Procedures....30-24
Brake System Checkout Sheet....30-34
Brake System Leakage Check....30-41
Brake Piston Leakage Test....30-42
Parking Brake Piston Leakage Test....30-43
Brake Floating Seal Pressure Test....30-43
Oil Separation Seal Pressure Test (Air Pressure Method)....30-43
Oil Separation Seal Pressure Test (Oil Pressure Method)....30-44
Wet Disc Brake Bleeding Procedure....30-44
Parking Brake Bleeding Procedure....30-45
Wet Disc Brake Wear Inspection....30-46
Parking Brake Wear Inspection....30-47
Accumulators and Suspensions....30-48
Bladder Accumulator Charging Procedure....30-48
Bladder Accumulator Leakage Test....30-49
Bladder Accumulator Storage....30-50
Piston Accumulator Charging Procedure....30-51
Piston Accumulator Leakage Test....30-52
Piston Accumulator Storage....30-53
Check for Improper Suspension Charge....30-54
Suspension Oiling and Charging Procedures....30-55
Oiling and Charging Tools and Support Blocks....30-56
Nitrogen Charging Kit Installation....30-60
Nitrogen Charging Kit Removal....30-60
Front Suspension Oiling and Charging....30-61
Rear Suspension Oiling and Charging....30-64

Suspension Pressure Test....30-67
Automatic Lubrication (Auto Lube) System....30-68
Prime the Auto Lube Pump....30-68
Prime the Auto Lube Grease Lines....30-68
Auto Lube System Checkout....30-69
Adjust the Auto Lube Cycle Timing (original IM only)....30-70
Adjust the Auto Lube Cycle Timing....30-71
Cab Air Conditioning....30-72
Refrigerant Leak Detection....30-73
A/C System Performance Test....30-73
Check the A/C System Oil....30-74
A/C System Flushing Procedure....30-75
Manifold Gauge Set Installation....30-76
Refrigerant: Recycled vs Reclaimed....30-77
Refrigerant Recovery Procedure....30-77
Evacuate the A/C System....30-77
Charge the A/C System....30-78
Electrical Systems....30-80
Shutdown Procedure for Drive System Service....30-80
Electrical System Checkout Procedures....30-81
Visual Checks....30-81
Resistance Checks....30-81
Voltage Checks....30-81
Truck Function Checks....30-84
Interface Module (IM) Checks....30-85
KOMTRAX Plus II Checks....30-85
Payload Meter (PLM) Checks....30-85
Drive System Checks....30-85
Engine Delayed Shutdown Smart Timer Check....30-86
Hoist Limit Switch Check....30-87
Electrical System Checkout Sheet....30-87
Interface Module (IM)....30-89
Interface Module Software and Tools....30-89
Interface Module Checkout Procedures....30-89
Setup for IM Realtime Monitor Software....30-89
Checking Digital Inputs to the IM....30-90
Checking Analog Inputs to the IM....30-91
Checking Serial Communication to the IM....30-92
Checking Outputs from the IM....30-92
Interface Module Checkout Sheet....30-93
Interface Module 2 (IM2)....30-96
Interface Module 2 Software and Tools....30-96
Program the IM2 Controller....30-96
Interface Module 2 Checkout Procedures....30-98
Check for IM Fault Codes....30-98
Checking Digital Inputs to the IM2....30-99
Checking Analog Inputs to the IM2....30-100
Checking Serial Communication to the IM....30-101
Checking Outputs from the IM2....30-101
Interface Module 2 Checkout Sheet....30-102
Payload Meter IV....30-105
Payload Meter IV Software and Tools....30-105
Payload Meter IV System Configuration....30-105
Configuring a Static IP Address....30-105
Payload Meter IV Software Installation....30-108
Payload Meter IV Data Downloading....30-108

This is the sample of the manual

Click on the download link for complete manual

Download Link

Payload Meter IV Checkout Procedure..... 30-109
Payload Meter IV Checkout Sheet..... 30-115
KOMTRAX Plus II..... 30-116
KOMTRAX Plus II Software and Tools..... 30-116
Komtrax Plus II Controller Ethernet Connection..... 30-116
KOMTRAX Plus II Configuration..... 30-117
GPS Connection Test..... 30-120
Satellite Connection Test..... 30-122
Komtrax Plus II System Initialization..... 30-125
KomVision..... 30-127
KomVision Setup and Calibration Requirements..... 30-127
KomVision Initial Setup and Checkout Procedure..... 30-127
KomVision Checkout Sheet..... 30-133
KomVision Calibration Sheets..... 30-135
Calibration Sheet Layout..... 30-135
Unfold and Fold Calibration Sheet..... 30-138
Calibration Sheet Placement..... 30-140
KomVision Camera Calibration Procedures..... 30-141
Automatic 6 Camera Calibration..... 30-141
Manual 6 Camera Calibration..... 30-144
1 Camera Calibration..... 30-146
KomVision Radar Setting Procedure..... 30-149
Komatsu Wireless Bridge (KWB)..... 30-152
Komatsu Wireless Bridge Software and Tools..... 30-152
Bullet Wireless Radio Configuration..... 30-152
Bullet Wireless Radio Installation..... 30-155
NanoStation Access Point Configuration..... 30-156
NanoStation Access Point Connection Test..... 30-158
Tire Monitoring System..... 30-160
Tire Monitoring System Software and Tools..... 30-160
Tire Monitoring System Software Installation..... 30-160
Tire Monitoring System Configuration..... 30-160
Connecting to the Tire Monitoring System Web Server..... 30-160
Configuring a Static IP Address..... 30-161
Tire Monitoring System Reset..... 30-163
Tire Monitoring System Checkout Procedure..... 30-163
Tire Monitoring System Checkout Sheet..... 30-165

**40 TROUBLESHOOTING..... 40-1**
Fuses, Diodes and Relays..... 40-2
Standard Truck Fault Codes..... 40-13
A001..... 40-13
A002..... 40-13
A003..... 40-14
A004..... 40-14
A005..... 40-15
A006..... 40-15
A007..... 40-16
A008..... 40-16
A011..... 40-17
A013..... 40-17
A014..... 40-18
A016..... 40-18
A017..... 40-18
A018..... 40-19

A019..... 40-19
A022..... 40-20
A101..... 40-20
A103..... 40-21
A104..... 40-22
A105..... 40-22
A109..... 40-23
A111..... 40-23
A115..... 40-24
A117..... 40-25
A118..... 40-25
A123..... 40-26
A124..... 40-27
A125..... 40-27
A126..... 40-28
A127..... 40-29
A128..... 40-29
A139..... 40-30
A145..... 40-30
A146..... 40-31
A152..... 40-32
A153..... 40-32
A154..... 40-33
A155..... 40-34
A158..... 40-35
A166..... 40-35
A167..... 40-36
A168..... 40-37
A169..... 40-37
A170..... 40-38
A171..... 40-38
A172..... 40-39
A173..... 40-39
A184..... 40-40
A190..... 40-41
A193..... 40-41
A194..... 40-42
A195..... 40-42
A196..... 40-43
A197..... 40-44
A198..... 40-44
A199..... 40-45
A200..... 40-45
A201..... 40-46
A202..... 40-46
A203..... 40-47
A204..... 40-47
A205..... 40-48
A206..... 40-48
A207..... 40-49
A213..... 40-50
A214..... 40-51
A215..... 40-52
A216..... 40-53
A223..... 40-53
A230..... 40-54

A231 ..... 40-55
A233 ..... 40-56
A235 ..... 40-57
A236 ..... 40-58
A237 ..... 40-59
A240 ..... 40-59
A242 ..... 40-60
A243 ..... 40-61
A244 ..... 40-61
A245 ..... 40-62
A246 ..... 40-63
A247 ..... 40-63
A248 ..... 40-64
A249 ..... 40-64
A250 ..... 40-65
A251 ..... 40-66
A252 ..... 40-67
A253 ..... 40-68
A256 ..... 40-68
A257 ..... 40-69
A258 ..... 40-70
A260 ..... 40-70
A261 ..... 40-71
A262 ..... 40-72
A264 ..... 40-73
A265 ..... 40-74
A266 ..... 40-74
A267 ..... 40-75
A268 ..... 40-76
A270 ..... 40-76
A272 ..... 40-77
A273 ..... 40-79
A274 ..... 40-79
A275 ..... 40-80
A277 ..... 40-81
A278 ..... 40-82
A279 ..... 40-83
A280 ..... 40-83
A281 ..... 40-84
A282 ..... 40-85
A283 ..... 40-85
A284 ..... 40-87
A285 ..... 40-87
A286 ..... 40-88
A292 ..... 40-89
A303 ..... 40-90
A304 ..... 40-91
A305 ..... 40-92
A307 ..... 40-92
A309 ..... 40-93
A310 ..... 40-94
A311 ..... 40-95
A312 ..... 40-96
A313 ..... 40-97
A315 ..... 40-97
A316 ..... 40-98

A317.....40-99
A318.....40-101
A328.....40-101
A332.....40-102
A333.....40-102
A334.....40-103
A335.....40-104
A337.....40-104
A338.....40-105
A339.....40-105
A340.....40-106
A341.....40-106
A342.....40-107
A343.....40-108
A344.....40-108
A345.....40-109
A346.....40-109
A347.....40-110
A348.....40-111
A349.....40-111
A350.....40-112
A351.....40-112
A352.....40-113
A353.....40-114
A354.....40-115
A355.....40-115
A356.....40-116
A357.....40-116
A358.....40-117
A359.....40-118
A360.....40-119
A361.....40-120
A362.....40-120
A363.....40-121
A364.....40-122
A365.....40-122
A366.....40-123
A400.....40-123
A401.....40-124
A402.....40-125
A403.....40-125
A404.....40-126
A405.....40-126
A406.....40-126
A407.....40-127
A408.....40-127
A409.....40-128
A410.....40-129
A411.....40-129
A412.....40-130
A413.....40-130
A414.....40-130
A415.....40-131
A416.....40-131
A417.....40-132
A418.....40-133

A419 ..... 40-133
A420 ..... 40-134
A421 ..... 40-134
A422 ..... 40-134
A423 ..... 40-135
A424 ..... 40-135
A425 ..... 40-136
A426 ..... 40-137
A427 ..... 40-137
A428 ..... 40-138
A429 ..... 40-138
A430 ..... 40-138
A431 ..... 40-139
A432 ..... 40-139
A433 ..... 40-140
A434 ..... 40-141
A435 ..... 40-141
A436 ..... 40-142
A437 ..... 40-142
A438 ..... 40-142
A439 ..... 40-143
A440 ..... 40-143
A441 ..... 40-144
A442 ..... 40-145
A443 ..... 40-145
A444 ..... 40-146
A445 ..... 40-146
A446 ..... 40-146
A447 ..... 40-147
Aftertreatment System Fault Codes ..... 40-148
CA256 ..... 40-148
CA1677 ..... 40-149
CA1678 ..... 40-151
CA1682 ..... 40-154
CA1683 ..... 40-162
CA1684 ..... 40-165
CA1685 ..... 40-166
CA1686 ..... 40-167
CA1695 ..... 40-168
CA1712 ..... 40-169
CA1713 ..... 40-170
CA1714 ..... 40-171
CA1715 ..... 40-172
CA1887 ..... 40-173
CA2771 ..... 40-173
CA3142 ..... 40-177
CA3143 ..... 40-178
CA3146 ..... 40-179
CA3147 ..... 40-180
CA3232 ..... 40-181
CA3497 ..... 40-184
CA3498 ..... 40-185
CA3547 ..... 40-186
CA3558 ..... 40-186
CA3559 ..... 40-188
CA3562 ..... 40-190

CA3563....40-191
CA3567....40-193
CA3571....40-195
CA3572....40-197
CA3573....40-200
CA3574....40-201
CA3575....40-202
CA3712....40-204
CA3713....40-205
CA3714....40-207
CA3867....40-208
CA3868....40-209
CA3878....40-212
CA3988....40-212
CA3995....40-216
CA4113....40-217
CA4114....40-218
CA4119....40-219
CA4121....40-219
CA4152....40-220
CA4164....40-223
CA4165....40-224
CA4166....40-227
CA4168....40-228
CA4169....40-230
CA4174....40-231
CA4175....40-233
CA4233....40-235
CA4234....40-236
CA4243....40-237
CA4277....40-238
CA4456....40-239
CA4457....40-247
CA4458....40-249
CA4459....40-251
CA4461....40-253
CA4462....40-254
CA4464....40-256
CA4465....40-259
CA4466....40-261
CA4467....40-269
CA4474....40-270
CA4475....40-272
CA4572....40-274
CA4677....40-279
CA4679....40-284
CA4682....40-285
CA4731....40-286
CA4732....40-286
CA4736....40-287
CA4737....40-288
CA4738....40-288
CA4739....40-289
CA4745....40-289
CA4768....40-290
CA4769....40-291

CA4842....40-292
CA4863....40-292
CA5115....40-293
CA5116....40-295
CA5117....40-298
CA5247....40-300
CA5653....40-301
CA5654....40-303
CA5725....40-304
CA5727....40-309
CA5728....40-312
CA5729....40-314
CA5748....40-315
CA5749....40-317
CA5751....40-319
CA5753....40-321
CA5755....40-324
CA5756....40-329
CA5758....40-331
CA5768....40-332
CA5769....40-334
CA5771....40-336
CA5772....40-338
CA5773....40-340
CA5774....40-343
CA5775....40-345
CA5776....40-351
CA5778....40-353
CA5779....40-354
CA5887....40-356
CA5888....40-357
CA5889....40-357
CA5891....40-358
CA5892....40-358
CA5893....40-359
CA6692....40-360
CA6693....40-360
CA6694....40-361
CA6695....40-362
CA6696....40-363
CA6697....40-364
CA6855....40-365
CA6856....40-367
KomVision Fault Codes....40-369
Troubleshoot the Steering System....40-380
Steering System Troubleshooting Guide....40-380
Basic Hydraulic System Checks....40-381
Steering/Brake Pump Troubleshooting Guide....40-382
Steering/Brake Pump Troubleshooting Checks....40-386
Steering/Brake Pump Fails to Unload....40-386
Steering/Brake Pump Fails to Develop Pressure....40-386
Steering/Brake Pump Slow to Develop Pressure....40-387
Steering/Brake Pump Control Valve Inspection....40-388
Steering/Brake Pump Case Drain Check....40-389
Troubleshoot the Auto Lube System....40-390
Troubleshoot the HVAC System....40-394

Control Panel Configurations....40-394
Diagnostics Mode....40-395
Error Codes....40-395
Advanced Diagnostics....40-395
Firmware Version....40-396
Additional HVAC Troubleshooting Chart....40-396
Voltage Levels....40-398
Troubleshoot the Electronic Fan Clutch....40-400

**50 DISASSEMBLY AND ASSEMBLY....50-1**
Special Tools List....50-2
Wheels, Spindles and Rear Axle....50-4
General Precautions for Tires and Rims....50-4
Lubricants for Tire and Rim Service....50-4
Tire Inflation....50-5
Rim Components....50-5
Wheel Stud Maintenance....50-6
Rear Outer Wheel Stud Installation....50-7
Front Wheel Removal....50-8
Front Wheel Installation....50-10
Rear Wheel Removal....50-11
Rear Wheel Installation....50-14
Lock Ring Removal....50-16
Lock Ring Installation....50-18
Tire Removal (Front 5-Piece Rim)....50-19
Tire Removal (Rear Outer 7-Piece Rim)....50-23
Tire Removal (Rear Inner 5-Piece Rim)....50-24
Tire and Rim Preparation....50-26
Tire Installation (Front 5-Piece Rim)....50-27
Tire Installation (Rear Inner 5-Piece Rim)....50-28
Tire Installation (Rear Outer 7-Piece Rim)....50-29
Front Wheel Hub and Spindle Removal....50-30
Spindle Removal While Off the Truck....50-36
Front Wheel Hub and Spindle Installation....50-37
Spindle, Hub and Brake Assembly Cross-Section View....50-41
Front Wheel Hub and Spindle Disassembly....50-42
Front Wheel Hub and Spindle Cleaning and Inspection....50-50
Front Wheel Hub and Spindle Assembly....50-51
Hub Floating Seal Installation....50-62
Rear Axle Removal....50-66
Rear Axle Cleaning and Inspection....50-68
Rear Axle Installation....50-68
Anti-Sway Bar Removal....50-69
Anti-Sway Bar Installation....50-72
Pivot Pin Removal....50-74
Pivot Pin Installation....50-75
Pivot Eye Bearing Wear Inspection....50-77
Pivot Eye Bearing Replacement....50-78
Pivot Eye Removal....50-78
Pivot Eye Installation....50-79
Wheel Motor Removal....50-80
Wheel Motor Cleaning and Inspection....50-83
Wheel Motor Installation....50-83
Steering System....50-88
Steering Control Unit Removal....50-88

Steering Control Unit Installation....50-89
Steering Control Unit Disassembly....50-91
Steering Control Unit Assembly....50-93
Steering Column Removal....50-96
Steering Column Installation....50-98
Steering Wheel Removal....50-100
Steering Wheel Installation....50-100
Bleeddown Manifold Removal....50-101
Bleeddown Manifold Installation....50-102
Flow Amplifier Removal....50-103
Flow Amplifier Installation....50-104
Steering Pin Joint Wear Inspection....50-105
Tie Rod Removal....50-107
Tie Rod Installation....50-108
Steering Cylinder Removal....50-110
Steering Cylinder Installation....50-111
Steering Cylinder Disassembly....50-112
Steering Cylinder Cleaning and Inspection....50-114
Steering Cylinder Assembly....50-115
Steering/Brake Pump Removal....50-117
Steering/Brake Pump Installation....50-118
Piston Steering Accumulator Removal....50-120
Piston Steering Accumulator Installation....50-122
Piston Steering Accumulator Disassembly....50-124
Piston Accumulator Cleaning and Inspection....50-126
Piston Seal Replacement....50-126
Piston Steering Accumulator Assembly....50-127
Brake System....50-130
Brake Valve Removal....50-130
Brake Valve Installation....50-131
Brake Valve/Pedal Disassembly....50-133
Brake Valve/Pedal Assembly....50-134
Front Brake Dual Relay Valve Removal....50-137
Front Brake Dual Relay Valve Installation....50-138
Rear Brake Dual Relay Valve Removal....50-139
Rear Brake Dual Relay Valve Installation....50-140
Brake Manifold Removal....50-142
Brake Manifold Installation....50-143
Brake Manifold Component Replacement....50-144
Piston Brake Accumulator Removal....50-145
Piston Brake Accumulator Installation....50-146
Piston Brake Accumulator Disassembly....50-148
Piston Accumulator Cleaning and Inspection....50-150
Piston Seal Replacement....50-150
Piston Brake Accumulator Assembly....50-151
Front Wheel Brake Disassembly....50-153
Front Wheel Brake Assembly....50-156
Rear Wheel Brake Removal....50-160
Rear Wheel Brake Installation....50-161
Rear Wheel Brake Disassembly....50-163
Rear Wheel Brake Assembly....50-167
Brake Floating Seal Installation....50-172
Wheel Brake Cleaning and Inspection....50-177
Wet Disc Brake Friction Disc Inspection....50-178
Wet Disc Brake Separator Plate Inspection....50-180
Friction Disc and Separator Plate Checkout Sheet....50-181

This is the sample of the manual

Click on the download link for complete manual

Download Link